



**Cybex® Plate Loaded Smith Press
Owner's and Service Manual
Strength Systems
Part Number 16120-999-4 D**



**Cybex® Plate Loaded Smith Press
Owner's and Service Manual**

Strength Systems
Part Number 16120-999-4 D

Cybex® and the Cybex logo are registered trademarks of Cybex International, Inc.

DISCLAIMER: Cybex International, Inc., makes no representations or warranties regarding the contents of this manual. We reserve the right to revise this document at any time or to make changes to the product described within it without notice or obligation to notify any person of such revisions or changes.

© Copyright 2010, Cybex International, Inc. All rights reserved.

Printed in the United States of America.

10 Trotter Drive Medway, MA 02053 • 508-533-4300 • FAX 508-533-5183

www.cybexinternational.com • techhelp@cybexintl.com • 16120-999-4 D • March 2010

Table of Contents

1 Safety	
Safety	1
Safety Guidelines and Practices	2
Warning/Caution Decals	3
Regular Maintenance Activities	4
2 Exercise	
Intended Use	4
Instructions	4
3 Customer Service	
Contacting Service	5
Ordering parts	6
Return Material Authorization (RMA)	6
Damaged Parts	7
4 Assembly	
Tools Required	7
5 Maintenance	
Daily Procedures	11
Weekly Procedures	11
6 Service	
Parts Lists	14
Exploded-View Diagram	15

1 - Safety


Safety

Read the Owner's Manual carefully before assembling, servicing or using Cybox equipment.



WARNING: Serious injury could occur if these safety precautions are not observed:

User Safety Precautions

- Obtain a medical exam before beginning any exercise program.
- Stop exercising if feeling faint, dizzy or experiencing pain and consult your physician.
- Obtain instructions before using. Lisez les instructions avant l'utilisation.
- Read and understand the owner's manual and all warnings posted on the machine before using. 
- Keep all children (12 and under) away. Teenagers (13 and over) and disabled must be supervised. Garder tous les enfants (de 12 ans et moins) éloignés. Les adolescents (de 13 ans et plus) et les handicapés doivent être surveillés.
- Use a spotter.
- Keep body and clothing free from and clear of all moving parts.
- Use the machine only for the intended use. **DO NOT** modify the machine.
- Inspect machine prior to use. **DO NOT** use if it appears damaged or inoperable.
- **DO NOT** attempt to fix a broken or jammed machine.
- Report any malfunctions, damage or repairs to the facility.
- Replace any warning labels if damaged, worn or illegible.

Facility Safety Precautions

- Read the Owner's Manual carefully before assembling, servicing or using this equipment.
- Make sure that each machine is set up and operated on a solid level surface. **Do not install equipment on an uneven surface.**

NOTE: *Cybox is not responsible for the actual anchoring of equipment. Consult with a professional contractor.*

NOTE: *Use fasteners having a minimum of 500 lbs. tensile capacity (3/8" grade 2 bolts or better).*

NOTE: *If legs/frame does not contact surface, DO NOT pull down with anchors. Shim any leg or frame not in contact with surface using flat washers.*

- Make sure that all users are properly trained on how to use the this equipment.
- Make sure there is enough room for safe access and operation of this equipment.
- Perform regular maintenance checks on this equipment. Also pay close attention to all areas most susceptible to wear.

Cybex Plate Loaded 16120 Smith Press Owner's Manual

- Immediately replace worn or damaged components. If unable to immediately replace worn or damaged components then remove from service until the repair is made.

NOTE: *It is the sole responsibility of the user/owner or facility operator to ensure that regular maintenance is performed.*

Safety Guidelines And Practices

Cybex recommends that all fitness equipment be used in a supervised area. It is recommended that the equipment be located in an access controlled area. Control is the responsibility of the owner. The extent of control is at the discretion of the owner.

It is the responsibility of the purchaser/user of Cybex products to read and understand the owner's manual, and warning labels; as well as instruct all individuals, whether end users or supervising personnel, on proper usage of the equipment.

PROPER USAGE:

Use machine only as described in the manual. Failing to follow proper instructions may result in injury.

Do Not Lean Against or Pull On the framework, weight stack, or any component, whether machine is at rest or in use. Inappropriate or improper use may result in injury to users or third parties (bystanders).

Do not use machine if it is not located on a solid level surface or is improperly installed.

Provide an adequate safety perimeter between the machine, walls and other equipment to ensure that the facility has the proper clearance for usage and training.

SECURING EQUIPMENT:

The machine has holes in the feet, which allow for ease in anchoring to the floor. Cybex strongly recommends that, to eliminate rocking, tipping or falling over due to incorrect usage and misuse, equipment be secured to a solid, level surface.

1. The solid, level surface should not deviate more than 1/8" over a 10' distance or as defined and required by local building and architectural codes.
2. Anchoring of equipment must be completed by a qualified licensed contractor.
3. Anchoring holes are provided on the feet of the frame. All anchoring locations must be used when anchoring the equipment to the floor.
4. Due to the wide variation of flooring on which machines may be anchored or installed, verify anchoring method and anchoring fasteners with a qualified and licensed contractor.
5. A minimum pull out force of 220 lbs/100 kgs is required for each anchor position..
6. Do not use machine until it is properly anchored.

MAINTENANCE:

Preventative maintenance allows proper equipment operation and reduces the risk of injury. Perform the maintenance requirements as specified in the manual.

STANDARD COMPLIANCE:

Cybex products meet or exceed applicable ASTM and EN Standards.



Warning/Caution Decals

Warning decals indicate a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

Caution decals indicate a potentially hazardous situation, which, if not avoided, could result in minor or moderate injury.

The following diagram shows where each decal is located.

WARNING

SERIOUS INJURY COULD OCCUR IF THESE PRECAUTIONS ARE NOT OBSERVED

1. Obtain a medical exam before beginning any exercise program.
2. Stop exercising if feeling faint, dizzy or experiencing pain and consult your physician.
3. Obtain instructions before using. *Lisez les instructions avant l'utilisation.*
4. Read and understand the owner's manual and all warnings posted on the machine before using.
5. Keep all children (12 and under) away. Teenagers (13 and over) and disabled must be supervised. *Gardez tous les enfants (de 12 ans et moins) éloignés. Les adolescents (de 13 ans et plus) et les handicapés doivent être surveillés.*
6. Use a spotter.
7. Keep body and clothing free from and clear of all moving parts.
8. Use the machine only for the intended use. **DO NOT** modify the machine.
9. Inspect machine prior to use. **DO NOT** use if it appears damaged or inoperable.
10. **DO NOT** attempt to fix a broken or jammed machine.
11. Report any malfunctions, damage or repairs to the facility.
12. Replace any warning labels if damaged, worn or illegible.

5220-364-4

Smith Press - 16120

DESCRIPTION	PART NO.
A. Warning Decal.....	5220-364-4
B. Warning Decal.....	16120-340-4
C. Warning Decal.....	16120-341-4

WARNING

UNHOOKED HOOKED

Serious injury can result if bar catch is not hooked properly and falls.

Make sure bar catch is fully engaged over hook to avoid injury.

WARNING

Serious injury or death may result if the adjustable bar stops are not set properly.

DO NOT start an exercise unless adjustable bar stops are in place.

PROPER use of adjustable bar stops allow an immediate exit in case of accident or emergency.

16120-340-4

WARNING

Serious injury or death may result if the adjustable bar stops are set **BELOW THIS** location when doing **SQUAT EXERCISE**.

DO NOT start **SQUAT EXERCISE** unless adjustable bar stops are in place.

PROPER placement of adjustable bar stops allow an immediate exit in case of accident or emergency.

16120-341-4

Regular Maintenance Activities

Preventative maintenance activities must be performed to maintain normal operation of this equipment. Keeping a log sheet of all maintenance actions will assist you in staying current with all preventative maintenance activities.



WARNING: *Equipment found to have worn or damaged components must be removed from service until repair(s) is made. Failure to do so could result in injury.*

Daily

1. Clean upholstery.

Weekly

1. Inspect all nuts and bolts for looseness. Tighten as required.
2. Check for worn handles, and worn warning labeling. Replace all worn parts immediately.

2 - Exercise


Intended Use

The intended use of this equipment is to aid or improve general physical fitness and exercise. For Commercial use.

Instructions

Read and understand all instructions and warnings prior to using this machine. See Chapter 1, Safety in Owner's Manual or consult with floor staff.

This machine is very versatile. Exercises that can be performed include: Squates, Bench and Incline Presses, Bent-Over Rows and Overhead Press.



NOTE: Refer to next page for set up and movement.

Set Up

1. Adjust bar to appropriate height for exercise. See Diagram A.
2. Adjust bar stops to appropriate height for exercise. See Diagram B.
NOTE: Ensure stops are set properly at equal height.
3. Load bar evenly with appropriate resistance.

NOTE: Unloaded bar weight = 15 pounds (7kg).




Diagram A




Diagram B

Movement

1. Position yourself for the exercise to be performed and grasp bar.
2. Lift bar rotate to release catch. See Diagram A.
3. Lift/lower bar with smooth, controlled movements.
4. Lock bar by rotating until catch is fully engaged. See Diagram A.
NOTE: Ensure bar catch is fully engaged over hook before releasing grip on bar.

3 - Customer Service

Contacting Service

Hours of phone service are Monday through Friday from 8:30 a.m. to 6:00 p.m Eastern Standard Time.

For Cybox customers living in the USA, contact Cybox Customer Service at **888-462-9239**.

For Cybox customers living outside the USA, contact Cybox Customer Service at **508-533-4300** or fax **508-533-5183**.

Find information on the web at www.cyboxintl.com or e-mail at techhelp@cyboxintl.com.

Ordering Parts

Fax orders to **508-533-5183**. To speak with a customer service representative, call **888-462-9239** (for customers living within the USA) or **508-533-4300** (for customers outside the USA). You may also contact us through e-mail at techhelp@cyboxintl.com.

Having the following information ready when calling, will assist our Cybox representatives in serving you.

- **Unit Serial Number**
- **Product Name**

The unit serial number and product name can be found on the serial number decal. See Chapter 6 for exact location of serial number decal.

- **Part Description**
- **Part Number**

Part descriptions and part numbers are located in Chapter 6 of this manual.

- **Shipping Address**
- **Contact Name**

In addition to your shipping address and contact name, your account number is helpful but not required.

Return Material Authorization (RMA)

The Return Material Authorization (RMA) system outlines the procedures to follow when returning material for placement, repair or credit. The system assures that returned materials are properly handled and analyzed. Follow the following procedures carefully.

Contact your authorized Cybox dealer on all warranty-related matters. Your local Cybox dealer will request a RMA from Cybox, if applicable. Under no circumstances will defective parts or equipment be accepted by Cybox without proper RMA and an Automated Return Service (ARS) label.

1. Call the Customer Service Hot Line listed above for the return of any item that is defective.
2. Provide the technician with a detailed description of the problem you are having or the defect in the item you wish to return.
3. Provide the model and serial number of your Cybox equipment.
4. At Cybox's discretion, the technician may request that you return the problem part(s) to Cybox for evaluation and repair or replacement. The technician will assign you a RMA number and will send you an ARS label. The ARS label and the RMA numbers must be clearly displayed on the outside of the package that contains the item(s) to be returned. Include the description of the problem, the serial number of the equipment and the name and address of the owner in the package along with the part(s).

5. Forward the package through UPS to Cybex.

Attn: Customer Service Department
Cybex International, Inc.
1975 24th Ave SW
Owatonna, MN 55060

NOTE: Merchandise returned without an RMA number on the outside of the package or shipments sent COD will not be accepted by the Cybex receiving department.

Damaged Parts

Materials damaged in shipment should not be returned for credit. Shipping damages are the responsibility of the carrier (UPS, Federal Express, trucking companies, etc.)

Apparent Damage - Upon receipt of your shipment, check all items carefully. Any damage seen with a visual check must be noted on the freight bill and signed by the carrier's agent. Failure to do so will result in the carriers refusal to honor your damage claim. The carrier will provide you with the required forms for filing such claims.

Concealed Damage - Damage not seen with a visual check upon receipt of a shipment but notices later must be reported to the carrier as soon as possible. Upon discovery of the damage, a written or phone request to the carrier asking them to perform an inspection of the materials must be made within ten days of the delivery date. Keep all shipping containers and packing materials as they will be needed in the inspection process. The carrier will provide you with an inspection report and the necessary forms for filing a concealed damage claim. Concealed damage claim is the carrier's responsibility.

4 - Assembly

Tools Required

- 9/16" Socket wrench
- 7/16" Wrench
- 7/32" Allen wrench
- 9/16" Wrench
- 5/16" Allen wrench

Smith Press - Product No.16120

Total Weight and Size

380 lbs. inches - 84 W x 54 L x 84 H
173 kg cm - 213 W x 137 L x 213 H

NOTE: *Three people will be required for this procedure.*

NOTE: *It is the responsibility of the facility owner/owner of the equipment to ensure that there is appropriate clearance around each machine to allow for safe use and passage.*

NOTE: *Refer to chapter 6 for reference diagrams.*

1. **Read and understand all instructions thoroughly before starting any of the procedures listed on this instruction sheet.**



2. Verify you have received the appropriate configuration.

- A. Verify that you received the correct color machine that you ordered.
- B. Verify you received the appropriate owner's manual.
- C. Verify you received the warranty sheet.

3. Move to desired location.

WARNING: Use extreme caution when removing Smith Press assembly from pallet. Failure to do so could result in injury.

NOTE: Keep all shipping packages near area of installation.

- A. Remove hardware pack and verify contents. See Figure 1.
- B. Carefully remove foam and shrink wrap securing frame mounts, set frame mounts aside.
- C. Carefully remove foam and shrink wrap securing weight bar to frame, set weight bar aside.
- D. Using a 7/32" Allen wrench and a 9/16" wrench remove the four Button Head Socket Cap Screws (BHSCS) from shipping bracket securing frame halves together.

NOTE: Do not discard BHSCS or locknuts.
- E. Using a 9/16" wrench remove the four lag bolts securing frame to pallet

NOTE: Carefully handle frame halves to prevent damage to paint or frame.

4. Assemble frame.

- A. With assistants hold frames in an upright position.
- B. Carefully place foot pad (supplied with machine) on each foot of the frame.
- C. Align front frame mount in place. See Figure 2.




Figure 2




Figure 1

- D. Using a 7/32" Allen wrench and a 9/16" wrench secure front frame mount in place with the four BHSCS and locknuts removed in step 3C.
- E. Place back frame mount in position. See Figure 3.




Figure 3

F. Using a 7/32" Allen wrench and a 9/16" secure back frame mount to frame with the four BHSCS and locknuts from shipping package. See Figure 3.

5. Install weight bar assembly.

- A. Carefully place weight bar on frame and secure in place by latching bar catch on hooks.
- B. Verify each bar catch is hooked properly on the hook. See Figure 4.




Figure 4

C. Slide bearing housing up (located at bottom of guide shaft) and align holes with weight bar bracket. See Figure 5.




Figure 5

- D. Locate four Socket Head Cap Screws (SHCS), four washers and loctite from shipping package.
- E. Place a small drop of loctite on the four SHCS and in threaded holes of weight bar bracket. See Figure 5.
- F. Place washer over SHCS.
- G. Using a 5/16" Allen wrench tighten the four SHCS securing the weight bar bracket to the bearing housing.
- H. Repeat steps 5C - 5F for opposite side.

6. Cable installation

- A. Locate two Hex Head Cap Screw HHCS from shipping package.
- B. Place a small drop of loctite on HHCS and in threaded hole.
- C. Using a 7/16" wrench, attach cable end to weight bar bracket with HHCS. **NOTE:** Cable end must be attached straight to avoid a kink in cable. See Figure 6.




Figure 6

- D. Repeat steps 6B and 6C for opposite cable end.

7. Securely anchor machine to the floor.

- A. Securely anchor machine to the floor using the anchor holes provided in each machine.

NOTE: Cybox is not responsible for the actual anchoring of equipment. Consult with a professional contractor.

NOTE: Use fasteners having a minimum of 500 lbs. tensile capacity (3/8" grade 2 bolts or better).

NOTE: If legs/frame does not contact surface, DO NOT pull down with anchors. Shim any leg or frame not in contact with surface using flat washers.

8. Verify proper operation.

5 - Maintenance

All preventive maintenance activities must be performed on a regular basis. Performing routine preventive maintenance actions can aid in providing safe, trouble-free operation of all Cybox Strength Systems equipment.

NOTE: *Cybox is not responsible for performing regular inspection and maintenance actions for your machines. Instruct all personnel in equipment inspection and maintenance actions and also in accident reporting/recording. Cybox phone representatives are available to answer any questions or concerns that you may have.*

Daily Procedures

1. **Upholstery** - Wipe down all upholstery.
2. **Frames** - Wipe down all frames using a mild solution of warm water and car wash soap. Be sure to dry thoroughly. **AVOID** acid or chlorine based cleaners and also cleaners containing abrasives as these could scratch or damage the equipment.
3. **Chrome** - Clean chrome tubes, first using chrome polish and then using a car wax seal. Neutral cleaners with a pH between 5.5 and 8.5 are recommended. Be sure to dry thoroughly. **AVOID** acid or chlorine based cleaners and also cleaners containing abrasives as these could scratch or damage the equipment.

Weekly Procedures

1. Inspect all nuts and bolts for looseness. Tighten as required
2. Inspect all labeling for readability. This includes instructional placards, warning and caution decals. Replace all worn labeling immediately.

6 - Service

Please refer to the next pages for parts lists and exploded-view diagrams

CAUTION


Use only Cybox replacement parts when servicing. Failure to do so could result in personal injury.

NOTE: All inspections and repairs must be performed by trained service personnel only.

Cybox will void warranty if non-Cybox replacement parts are used.

Plate Loaded Smith Press

PRODUCT NO. 16120



DESCRIPTION	PART NO.	DESCRIPTION	PART NO.
A. Placard.....	16120-598-X	D. Warning Decal.....	5220-364-X
B. Warning Decal.....	16120-340-X	E. Serial Number Decal	
C. Warning Decal.....	16120-341-X	F. Caution Decal.....	4000Y316-X


ITEM	QTY	PART NO.	DESCRIPTION
34	4	BR030204	RETAIN RING LINEAR BRG 1.00
35	2	BR030222	INTERNAL RETAINING RING, 52 MM
36	2	BR030223	EXT RETAINING RING, 25 MM
37		CM000211	DECAL, PATENT PENDING (REMOVED 7/6/09)
38	4	FB030234	BEARING, RADIAL
39	4	FB030257	BEARING, RADIAL 10MM EXTENDED RACE
40	4	FB050226	BEARING, FLANGE 1.000 ID x 1.25 OD x 1.00 LG
41	4	FB110201	BRG, RADIAL
42	4	FS110201	SEAL, LINEAR BRG 1.00
43	2	HC621215	HX HD CAP .250-20 X 7.50
44	8	HC700430	BHSCS .375-16 X 2.50
45	2	HC700432	BHSCS .375-16 X 2.75
46	28	HF540200	GROMMET, NYLON
47	2	HN704400	NUT, HEX JAM .375-16
48	24	HN704901	LOCKNUT, .375-16 NYLON
49	4	NA	
50	28	HT542514	PN HD PHIL SC # 8 X .625 BLK
51	4	HY623410	SET SCREW
52	12	JC700420	BHSCS .375-16 X 1.25
53	2	JC700424	BHSCS .375-16 X 1.75
54	8	JC702820	SHCS .375-16 X 1.25
55	NA		
56	2	PP130003	INSERT, DOMED PLASTIC
57	10	PP130006	INSERT, PLASTIC END
58	4	16120-340-X*	DECAL, WARNING
59	4	16120-341-X*	DECAL WARNING
60	1	16120-598-X*	PLACARD (SMITH PRESS)
61	1	5220-364-X*	DECAL, WARNING
62	8	HS348300	LOCKWASHER SPLIT .375
63	2	HC620431	BHSCS .250-20 X 2.00
64	2	HN625200	LOCKNUT .250-20 NYLON
65	2	4000Y316-X*	DECAL, CAUTION
66	1	11040-790	DECAL, MADE IN USA

ITEM	QTY	PART NO.	DESCRIPTION
1	2	11090-385	GRIP
2	6	16010-311	FOOT PAD
3	2	16120-002	CABLE ASSEMBLY
4	1	16120-200	FRAME LH
5	1	16120-201	FRAME RH
6	1	16120-202	FRAME MOUNT
7	1	16120-203	FRAME MOUNT
8	1	16120-204	WEIGHT BAR
9	2	16120-205	BEARING HOUSING
10	1	16120-206	WEIGHT BAR BRACKET LH
11	1	16120-207	WEIGHT BAR BRACKET RH
12	1	16120-208	CATCH LH
13	2	16120-209	BACKING PLATE
14	1	16120-211	CATCH RH
15	4	16120-308	PLATE, MOUNTING HOOKS
16	4	16120-318	BUSHING
17	2	16120-351	COUNTERWEIGHT
18	NA	16120-343	CAPLUG (REMOVED 7/27/09)
19	4	16120-344	CAPLUG, MODIFIED
20	2	16120-345	SPACER
21	2	16120-346	BEARING HOUSING
22	NA		
23	3	3900-443	DECAL, CYBEX 1.00 HOR (BLACK)
23	3	3900-444	DECAL, CYBEX 1.00 HOR (SILVER)
24	2	4400-354	PULLEY, 3.50 INCH
25	1	51198	WARRANTY BOOK (NOT SHOWN)
26	8	5220-367	SPACER, PLASTIC
27	2	5340M042	SHAFT 1.00 DIA X 79.88
28	2	5340P003	WEIGHT TUBE 6.00
29	NA		
30	2	5341-340	SPACER
31	2	5341-365	WEIGHT TUBE
32	4	5490P009	WEIGHT TUBE 10.00
33	2	5490P010	WEIGHT TUBE 8.00


***Language Key**


1-German, 2-French, 3-Spanish, 4-English, 6-Japanese,
7- Swedish, 8- Russian

16120 SMITH PRESS HANDLE DETAIL



16120 SMITH CABLE ROUTING DETAIL







10 Trotter Drive Medway, MA 02053 • 508-533-4300 • FAX 508-533-5183
www.cybexinternational.com • techhelp@cybexintl.com